

How to connect adapter cable 70ADA00101 to Transmitter OEM202R.
(Adapter cable 70ADA00101 should be used together with adapter cable 4004430401 for connection to USB-Interface ICON-X)

Off-line communication (transmitter not connected to external power supply).

Cable color	Connection on PCB
Green	A+
White	B-
Red	LOOP+
Black	LOOP-

On-line communication (transmitter connected to external power supply).

Cable color	Connection on PCB
Green	A+
White	B-

Connect communication cable after power supply to the transmitter is switched on and after transmitter start up.

